

ARCHIVE 2011

OF MATERIAL IMPORTANCE

Electroformed Barrels for Fine Pitch Test Probes

Larre Nelson, John Winter—Rika Denshi America

Solder Migration DoE for Pin

Chen Yong Lai—Test Tooling Solutions Group

Challenges & Solutions For Characterization of Thin Connector Alloy Strip

John C. Harkness—Brush Wellman Inc.

COPYRIGHT NOTICE

The papers in this publication comprise the pre-workshop Proceedings of the 2011 BiTS Workshop. They reflect the authors' opinions and are reproduced here as they are planned to be presented at the 2011 BiTS Workshop. Updates from this version of the papers may occur in the version that is actually presented at the BiTS Workshop. The inclusion of the papers in this publication does not constitute an endorsement by the BiTS Workshop, the sponsors, BiTS Workshop LLC, or the authors.

There is NO copyright protection claimed by this publication. However, each presentation is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author/s or their companies.

The BiTS logo and 'Burn-in & Test Socket Workshop' are trademarks of BiTS Workshop, LLC.

Electroformed Barrels for Fine Pitch Test Probes

Larre Nelson
John Winter

Rika Denshi America




2011 BiTS Workshop
March 6 - 9, 2011



Content

- Electroforming Basics
- *e-barrel*TM Manufacturing
- *e-barrel*TM Characteristics
- Test Results

What is Electroforming ?




How to make an electroformed BiTS logo.

3/2011


Electroformed Barrels for Fine Pitch Test Probes

3

Miniature Electroformed Parts




Gears



Cantilevers



Barrels & Ferrules



Test Probes


3/2011

Electroformed Barrels for Fine Pitch Test Probes

4

Electroformed Test Probe Barrels

Wire Core



Electroformed Gold over the Wire





Electroformed Nickel over the Gold



Extraction of Wire Core



Cut to Desired Barrel Length



3/2011

Electroformed Barrels for Fine Pitch Test Probes

5

e-barrel™ Features

- OD 0.085 mm (0.0033")
- Wall Thickness 0.0075 mm (0.0003")
- Gold on ID 1.5 μ m (60 μ ") over entire length
- Temperature Rating Gold on ID is non-oxidizing up to 175+°C

3/2011

Electroformed Barrels for Fine Pitch Test Probes

6

Machined Barrels



Machined from Tube



Machined from Solid Rod

3/2011


Electroformed Barrels for Fine Pitch Test Probes

7

Clad Tubes



Welded Strip




Seamless Tube

3/2011

Electroformed Barrels for Fine Pitch Test Probes

8

Deep Drawn Barrels



Strip material is fed into a sequence of dies.

3/2011

Electroformed Barrels for Fine Pitch Test Probes

9

*e-barrel*TM Manufacturing Process (Rack Plating Method)



The process is similar to making candles.

3/2011

Electroformed Barrels for Fine Pitch Test Probes

10

*e-barrel*TM Manufacturing Process (Continuous Plating Method)



A typical continuous wire plating line.

3/2011

Electroformed Barrels for Fine Pitch Test Probes

11

*e-barrel*TM Manufacturing Process (Cut to Specified Length)



Long tubes are cut to length like logs in a saw mill.

3/2011

Electroformed Barrels for Fine Pitch Test Probes

12

*e-barrel*TM Manufacturing Process



Of course, it's always good to have a back-up plan.

3/2011


Electroformed Barrels for Fine Pitch Test Probes

13

Wall Thickness



Thin walls with concentric
ID and OD. (OD: 0.3 mm)



Gold plating on the ID.
(Au: 1.5 μm , Ni: 13.5 μm)

3/2011


Electroformed Barrels for Fine Pitch Test Probes

14

Surface of the Barrel ID



e-barrel™



**Standard barrel:
6X rougher than
*e-barrel™***

3/2011

Electroformed Barrels for Fine Pitch Test Probes

15

Barrel OD and Length



**Top OD: 0.350 mm
Bottom OD: 0.085 mm**



**Top barrel: 5.6 mm long
Bottom barrel: 3.0 mm long**

3/2011

Electroformed Barrels for Fine Pitch Test Probes

16

Gold Plating on the ID



e-barrel™: open end



e-barrel™: middle section



Standard barrel: open end



Standard barrel: middle section

3/2011

Electroformed Barrels for Fine Pitch Test Probes

17

e-barrels™ for Fine Pitch Test Probes

Features

- Small OD
- Thin Wall
- Various ODs and Lengths
- Uniform Plating on ID
- Thick Plating on ID

Benefits


- Fine Pitch
- Maximum Space for Spring
- Custom Requirements
- Low CRES, and High Durability
- High Temperature Rating

3/2011

Electroformed Barrels for Fine Pitch Test Probes

18

0.2 mm Pitch Test Probe




3/2011

Electroformed Barrels for Fine Pitch Test Probes

19

0.5 mm Pitch Test Probe (Baked, then cycled at 175°C)



3/2011

Electroformed Barrels for Fine Pitch Test Probes

20

Prediction of Things to Come

- Smaller pitch
- Rigorous spring force and travel requirements
- Higher temperatures (→ 175°C)

3/2011

Electroformed Barrels for Fine Pitch Test Probes

21

Acknowledgements



T. Kohtaka
Kumamoto, Japan



W. Shiratani
Kumamoto, Japan



S. Amadio
Attleboro, Mass. USA

3/2011

Electroformed Barrels for Fine Pitch Test Probes

22

Solder Migration DoE for Pin

Lai Chen Yong
Test Tooling Solutions Group



2011 BiTS Workshop
March 6 - 9, 2011



Content

- Objective
- DoE Set Up
- Lab Data (CRES data for particular cycle intervals)
- Conclusion

Objective

- DoE on different pin tip material and plating to address the solder migration issue

3/2011

Solder Migration DoE for Pin

3

DoE Set Up

- BGA pin types details

Pin Type	Base material	Hardness	Plating
Type 1	BeCu	380HV	Au/PdCo/Ni
Type 2	SK4	650HV	Au Over Ni
Type 3	BeCu	380HV	Nano Coating On Au Over Ni
Type 4	Paliney 7	427HV	No plating
Type 5	BeCu	380HV	Au Over Ni
Type 6	SK4	650HV	Au/PdCo/Ni


3/2011

Solder Migration DoE for Pin

4

DoE Set Up

- 6 types of pins are populated in one test contactor




- Using BGA mechanical package for cycling test

3/2011

Solder Migration DoE for Pin

5

Lab Data: Variability Chart (0-15k)




- Up to 15k, Type 5 pin lowest CRES mean & stdev.
- Type 4 pin shown the highest CRES mean & stdev after 15k
- Best to worst : T5 -> T1/T2/T3/T6 -> T4

3/2011

Solder Migration DoE for Pin

6

Lab Data: Variability Chart (20-50k)




- From 20-50k, **Type 1, 2 & 5** pin with lowest CRES mean & stdev.
- **Type 4 & 6** pin shown the highest CRES mean & stdev.
- Best to worst : T1/T2/T5 -> T3 -> T4/T6

3/2011

Solder Migration DoE for Pin

7

Lab Data: Variability Chart (60-100k)




- From 60-100k, **Type 1 & 2** pin with lowest CRES mean.
- Best to worst : T1/T2 -> T3/T5/T6 -> T4

3/2011

Solder Migration DoE for Pin

8

Lab Data: Variability Chart (300-500k)



- Type 1 & 2 still show the lowest mean & smaller spread among all.

3/2011

Solder Migration DoE for Pin

9

Conclusion

- Type 5 (BeCu/AuNi) pin tip didn't show major impact on the solder migration issue as it works normally after the brushing process.
- Type 1 (BeCu/PdCo) & type 2 (SK4/AuNi) pin showed lower mean CRES up to 500k cycles, and was consistent along all the test intervals from the DoE.
- Pin's CRES is able to reduced to acceptable region after the brushing process in all cycle intervals regardless of the pin type in different material and plating.

3/2011

Solder Migration DoE for Pin

10

CHALLENGES & SOLUTIONS FOR CHARACTERIZATION OF THIN CONNECTOR ALLOY STRIP

John C. Harkness FASM
Principal Scientist
Brush Wellman Inc.



2011 BiTS Workshop
March 6-9, 2011



Outline

- Thin strip – challenges for property testing
- New test methods for thin strip:
 - Issues with Near Elastic Properties
 - “Multiple Beam Width Test” for Bend Formability
 - Fatigue Tests:
 - “Creep Bending Fatigue Test” Machine
(R = 0 unidirectional bending ONLY)
 - “Ductility Fatigue Flex Tester”
(R = -1 fully reversed bending ONLY)
 - Ductility Measurement via “Flex Tester”
 - “Mandrel Test” for Stress Relaxation Resistance
- New vs Traditional Property Test Comparisons
- Conclusions & Acknowledgements

Challenges of Thin Strip (I)

- Miniaturization of contacts = driving force for very thin strip
 - Currently as thin as 0.0012 in. – 0.0008 in. (0.03 mm to 0.02 mm)
- Designers still expect traditional mechanical and physical property test results at thin delivered gauges

3/2011 Challenges & Solutions for Characterization of Thin Connector Alloy Strip

3

Challenges of Thin Strip (II)

- *Potential* “thickness effects” in strip
 - Microstructural features such as grain size and intermetallic particles may NOT “scale down” proportional to thickness reduction
 - Metallurgical processes may differ
 - More intermediate anneals to thin gauges
 - Compromises on proprietary process parameters due to equipment limitations at thin gauges

3/2011 Challenges & Solutions for Characterization of Thin Connector Alloy Strip

4

Challenges of Thin Strip (III)


- Traditional property testing equipment **CANNOT** handle very thin strip
 - “Near elastic” property tests are compromised or impossible
 - **Spring Bend Limit** – must use shorter span & lower permanent set criterion to define bending yield strength
 - **Elastic Limit in Tension** – test apparatus weight alone causes plastic deformation (or fracture!) before Elastic Limit can be determined
 - Traditional **Tensile Elongation** measurement is difficult
 - **Stress Relaxation/Fatigue** -- cannot achieve desired **Initial Stress** levels *in bending* with traditional tapered cantilever beam lengths/deflections

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip


5

“Near Elastic” Property Tests



Spring Bend Limit
(Bending Stress for
50 microns set)

- Stepwise load/unload 3-point bend
- **CAN test thin strip** by shortening span & dropping to 25 microns set



Elastic Limit in Tension
(0% offset YS)


- Stepwise load/unload of strain-gauged tensile specimen
- Detect 1st microstrain of set
- **CANNOT test thin strip** – weight pan alone causes plastic yielding

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip


6

Traditional “Plane Strain” Bend Formability Test



“Plane strain” (beam $W/t \gg 10-12$)
using 90 deg V-block & a series of
punches of radius R

- Longitudinal & Transverse bends
 - Ultra conservative measure of R/t min for no cracking
 - Test data *appear* less “competitive”



- Hard to discriminate small differences in R/t min at very thin t (finite series of R 's)

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

7


New “Multiple Beam Width” Bend Formability Test




Brush Wellman pneumatic press
& die (5 slots in single stroke)

Test coupon (originally
designed by Molex & Wieland)

- “Plane strain” ($W/t < 10-12$)
to “plane stress” ($W/t \gg 10-12$)
- More “competitive” R/t min in
narrower beams



Bent test coupon (run series of R 's)



3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip


8

Traditional Tapered Cantilever Beam Fatigue Tester (Fatigue Dynamics)

Fully Reversed ($R = -1$) & Unidirectional ($R = 0$) Bending




Shut-down controller & cam drive



Multiple specimen fixture -- individual counters shut-down at fracture

- Tip deflection = stress



Tapered beam specimen
intended for 0.005-0.020" strip

- In practice, 0.00787" min
- Can't detect failed thin strip
- Machine is out of production


3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

9

New "Creep Fatigue Tester" (Nippon Bell Parts, Japan)

Unidirectional Bending
ONLY ($R \sim 0$)



- For 0.02-0.2 mm strip
- Tension, R slightly > 0
- Test pulley radius = stress
- Tests multiple specimens with individual counters stopping at break





Photo etched "dog bone"
test specimen

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

10

New “Ductility Fatigue Flex Tester”


(Jovil Mfg.)

Fully Reversed ($R = -1$) Bending Only




Tester w/cycle counter

- Tests flat flexible cable & foil gauge strip
- Single specimen only



Strip path -- guide rolls

- Mandrel dia. = stress
- $t \ll 0.00787$
- Insufficient stress levels (mandrels) for $t > 0.00787$



Precision specimen shear (Thwing-Albert)

- $\frac{1}{4}$ " X 12" rectangles
- Duct tape leaders from specimen ends to suspended weight
- Conforms specimen to mandrel

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

11

“Flex Tester” DUCTILITY Measure (I)

(Per ASTM E 796-94, “Standard Test Method for Testing Ductility of Metallic Foil”)

- Ductility measurement satisfactory for acceptance testing of commercial strip, manufacturing control & component design
- Alternative to tensile elongation methods of ASTM E 345-93, “Standard Test Methods of Tension Testing of Metallic Foil”
 - 2" gauge length = change in length between light scribe marks after pulling to fracture
 - 5" gauge length = taken from load-elongation graph to failure (on a positive head-speed type machine)

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

12

“Flex Tester” DUCTILITY Measure (II)

- Run “Flex Tester” at a mandrel dia. small enough (stress high enough) to give 30-500 cycles to failure
- Iteratively solve empirical equation:

$$N_f^{-0.6} D_f^{0.75} + 0.9(S_u/E) * [(S_f/S_u)(\exp(D_f)/0.36)]^{0.1785 \log(10^5/N_f)} - 2t_M/(2p + t) = 0$$
 - N_f = cycles to failure
 - D_f = fatigue ductility(X100%)
 - S_u , S_f & E = tensile strength, fracture strength & modulus in tension
 - t , t_M = thickness & min. core thickness (t – surface features)
 - $2p$ = mandrel dia.
 - Terms combine Manson-Coffin plastic strain/fatigue life relationship, elastic strain-fatigue life relationship & cyclically applied strain range
 - Programmable calculator/spreadsheet solution routines available
- Repeat for multiple specimens & report average D_f

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

13

“Flex Tester” DUCTILITY Measure (III)


- Formula for computing D_f in published ASTM specification was *incorrect*
 - Formula in previous slide (#13) has been corrected
- ASTM E 796-94 was actually WITHDRAWN in 2009
 - Failure to update within 8 years of last update
- Brush Wellman has had few problems testing elongation in thin strip per ASTM E 345-93 using low capacity horizontal tensile testers to pull CNC-milled “dog bone” specimens

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

14

Traditional Stress Relaxation Test




- Tapered cantilever beam stressed in bending
- Difference between initial deflection & tip set after thermal exposure for various times = “% Remaining Stress”
- CANNOT deflect tip enough to apply 0.75% of 0.2%YS Initial Stress at very thin gauge, nor “scale down” fixture for shorter, thinner beams

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

15

New “Mandrel Test” for Stress Relaxation



- Sheared rectangle
- Suitable for very thin strip
- Wrap around mandrel with metal hose clamp
- Mandrel dia. = Initial Stress
- Difference between mandrel radius & specimen set radius of curvature after thermal exposure for various times = “%Remaining Stress”
- Downside = must custom machine mandrels for each material & strip thickness

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

16

Test Method Comparisons

*Bend Formability
Fatigue
Stress Relaxation*



- *Graphs in examples reduced in size – fonts hard to read*
- *Key points of comparison highlighted by enlarged labels, trend direction arrows and/or figure captions*

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

17

Bend Formability Test Comparison (I)



0.0063"
Alloy
190
XHM

Multiple Beam Width (MBW) Bend Test – Color contour plots of Bend Surface Appearance Rating vs. $y = \text{beam Width}/t$ & $x = \text{punch R}/t$

Red-yellow = rough/unacceptable Surface Appearance Ratings ($> \#4$) on a scale of $\#1 = \text{smooth}$ to $\#5 = \text{open crack}$

Green = typical acceptance limit for bend surface roughness ($\sim \#3$ Rating)

Blues = smoothest, preferred Bend Surface Ratings ($\#2 - \#1$)


3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

18

Bend Formability Test Comparison (II)

Unique Use of "MBW Bend Test" Data



Superimpose Contours for Selected Surface Rating#
on a Plot of W/t vs. R/t



- Compare performance of same material vs. thickness
- Compare performance of different materials at ~ same thickness

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

19

Bend Formability Test Comparison (III)



MBW Test Surface Rating vs R/t curves at several W/t's compared to Traditional Bend Test R/t min values (example = 0.010" Alloy 190 XHM)

- GW bends at test W/t's do NOT pass #3 Rating at published 1 R/t min
- BW bends at test W/t's all pass #3 Rating at published 5 R/t min



IN MOST CASES MBW Test #3 Rating correlates well with Traditional Test published R/t min for W/t >> 10-12 (Plane Strain)

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

20

Fatigue Test Comparison (I)



Nippon Bell Parts "Creep Fatigue Test" S-N data for thin Alloy 190 & Brush 60 at $R \sim 0$:

- Correlates well with Traditional Test $R = 0$ for thick Alloy 190 & Brush 60
- Shows superior Fatigue Strength to Traditional Test $R = -1$ (as expected)


3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

21

Fatigue Test Comparison (II)

Mill Hardened BrushForm158tm



"Flex Tester"
 $R = -1$ S-N curves
for thin BF158tm
(C72900)
correlate well with
Traditional Test
 $R = -1$ curve for
thicker Pfinodaltm
C729

Alloy 190 $R = -1$
Traditional Test
curve shown for
comparison



3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

22

Stress Relaxation Test Comparison

(%RS vs Time curves for C72900 CuNiSn Strip)



“Mandrel Test” vs Traditional Tapered Cantilever Beam Test:

- Thermal relaxation rates comparable (slopes of %RS vs Time curves)
- “Mandrel Test” = greater initial “mechanical relaxation” (set) at Room T
 - Compensate by “translating” curves up until 1 hr data point >95 %RS

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

23

Conclusions (I)

- Decreasing strip gauge introduces challenges in traditional property tests:
 - Premature plastic deformation in “Near Elastic” strength tests (Spring Bend Limit, Elastic Limit)
 - Inability to discriminate small differences in bend formability in “Plane Strain” V-block Test
 - Inability to achieve target stresses in bending via tapered beam specimen deflection (Fatigue, Stress Relaxation)

3/2011

Challenges & Solutions for Characterization of Thin Connector Alloy Strip

24

Conclusions (II)

- New test methods have been identified that overcome most testing challenges in thin strip
 - Simple adjustments to Spring Bend Limit Test parameters (but -- NO Elastic Limit Test alternative)
 - “Multiple Beam Width Bend Formability Test”
 - Novel Fatigue Tests
 - Nippon Bell Parts “Creep Fatigue Test” ($R \sim 0$)
 - “Ductility Fatigue Flex Tester” ($R = -1$)
 - “Mandrel Test” for Stress Relaxation

3/2011 Challenges & Solutions for Characterization of Thin Connector Alloy Strip

25

Conclusions (III)

- New property tests generally correlate well with traditional test method results
 - “Multiple Beam Width” Bend Test typically gives acceptable #3 surface appearance rating in Plane Strain ($W/t \gg 10-12$) at R/t published for Plane Strain V-block Test
 - “Creep Fatigue Test” ($R \sim 0$) & “Flex Test” ($R = -1$) give S-N curves comparable to Tapered Cantilever Beam Tests
 - “Mandrel Test” gives Stress Relaxation curves comparable in thermal relaxation rate to Tapered Cantilever Beam Test
- Differences mainly attributable to mechanical effects
 - Tensile component in “Creep Fatigue Test” (R slightly > 0)
 - Increased Room Temp. set in “Mandrel Test”, shifting %RS vs. Time curves downward compared to Tapered Beam Test
- No *conclusive* evidence of metallurgical or processing “thickness effects” on new test outcomes

3/2011 Challenges & Solutions for Characterization of Thin Connector Alloy Strip

26

Acknowledgements

- **John Wetzel** at Brush Wellman (Reading, PA) for acquiring pneumatic press and special die for “MBW Bend Test”, and all thin strip for new test methods
- **Ted Skoraszewski** at Reading for running “MBW Bend Tests” of thin strip
- **Joshua Caris** at CWRU's Center for Mechanical Characterization of Materials for guidance in “Flex Tester” set-up & operation
- **John Fox** at Brush Wellman (Elmore, OH) for running “Flex Tester” fatigue & “Mandrel” stress relaxation tests (as well as traditional tests)
- **Tadashi Suzuki** at Brush Wellman (Japan) Ltd. for coordinating “Creep Fatigue Tests” of thin Brush Wellman strip at Nippon Bell Parts
- **Michael Gedeon** at Brush Wellman (Cleveland, OH) for helpful review, formula correction for “Flex Tester” Ductility Measurement & creation of solution spreadsheet