BiTS 2015

Proceedings Archive



Proceedings Archive

Copyright Notice

The presentation(s)/paper(s) in this publication comprise the Proceedings of the 2015 BiTS Workshop. The content reflects the opinion of the authors and their respective companies. They are reproduced here as they were presented at the 2015 BiTS Workshop. This version of the papers may differ from the version that was distributed in hardcopy & softcopy form at the 2015 BiTS Workshop. The inclusion of the presentations/papers in this publication does not constitute an endorsement by BiTS Workshop or the workshop's sponsors.

There is NO copyright protection claimed on the presentation content by BiTS Workshop. However, each presentation is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author(s) or their companies.

The BiTS logo and 'Burn-in & Test Strategies Workshop' are trademarks of BiTS Workshop. All rights reserved.



Poster Session





Kelvin Contact Solution for WLCSP

Jay Kim, Daniel Shin LEENO Industrial Inc.


Problem Statement

- Portable and wireless devices have prompted smaller packaging and dense IC devices.
- The demand for thinner packages and WLP (Wafer Level Package) has increased.
- WLP testing requires higher accuracy and precision.
- The use of Kelvin probes becomes the solution of choice which, in turn, creates further issues with Ball Contact and Current Carrying Capacity.


Test Set Up #1: (Ball Contact)

- Mount General Kelvin and Improved Kelvin Probes into respective sockets
- Contact both probes onto balls
- Measure distance and capture images of ball marks

General Kelvin Probe





Improved Kelvin Probe



Test Results:

- Probe marks
- Mark distance







Poster Session

Test Set Up #2:

(Current Carrying Capacity)

- Set up same-sized and different-sized pairs of Kelvin probes. On different-sized pairs, thicker probe is for power and the other for sense. Fig 1.
- Flow 0.5A to each pin for ten minutes and then measure the forces and CRES of the pins how much they can pass the flow. Fig 2








Fig 1. Different Pin Size for Force Pins

Fig 2. Current Flow and Force/CRES Measurement





BiTS 2015

BITO 2013

Poster Session

Summary:

(Ball Contact)

 Improved Kelvin Probes (LK Probe) provide optimal ball contact (smaller and shorter distance ball marks) compared to General Kelvin Probes

(Current Carrying Capacity)


 Compared to same-sized Kelvin probes, different-sized Kelvin probes provide higher Current Carrying Capacity

Recommendation:

General LEENO Kelvin Socket Structure









High Force LEENO Kelvin Socket Structure







BiTS 2015

Kelvin Contact Solution for WLCSP

3