Proceedings



Burn-in & Test Strategies Workshop

www.bitsworkshop.org

Proceedings

Session 5 Ashok Kabadi

Asnok Kabadi Session Chair

BiTS Workshop 2015 Schedule

Performance Day

Tuesday March 17 10:30 am

Handle With Care

"Semi Automated DIB/PIB Loader"

Alexander Wieler - esmo AG

"Mechanical Flip Burn In (FBI) for Tire Pressure Monitoring System"

Raimondo Sessego, James Stanley, & Joe Milazzo - Freescale Semiconductor

"Final Test Solution of WLCSP devices"

Mike Frazier- Xcerra Corporation



Burn-in & Test Strategies Workshop

Copyright Notice

The presentation(s)/paper(s) in this publication comprise the Proceedings of the 2015 BiTS Workshop. The content reflects the opinion of the authors and their respective companies. They are reproduced here as they were presented at the 2015 BiTS Workshop. This version of the papers may differ from the version that was distributed in hardcopy & softcopy form at the 2015 BiTS Workshop. The inclusion of the presentations/papers in this publication does not constitute an endorsement by BiTS Workshop or the workshop's sponsors.

There is NO copyright protection claimed on the presentation content by BiTS Workshop. However, each presentation is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author(s) or their companies.

The BiTS logo and 'Burn-in & Test Strategies Workshop' are trademarks of BiTS Workshop. All rights reserved.



Burn-in & Test Strategies Workshop

www.bitsworkshop.org

BiTS 2015

Handle With Care - Test Cell Integration

Final Test Solution of WLCSP Devices

Mike Frazier Xcerra Corporation



2015 BiTS Workshop March 15 - 18, 2015



Burn-in & Test Strategies Workshop

www.bitsworkshop.org

Handle With Care - Test Cell Integration

BiTS 2015

Agenda

- WLCSP Final Test
 - Process flow and equipment required
- InCarrier design and features
 - InCarrier Anatomy
 - Results
- Data Tracking
 - Wafer data @ final test
- Test Cell efficiency



Final Test Solution of WLCSP Devices

BiTS 2015

Handle With Care - Test Cell Integration



Burn-in & Test Strategies Workshop

www.bitsworkshop.org

BiTS 2015

Handle With Care - Test Cell Integration

Simplified Process Flow Comparison



Burn-in & Test Strategies Workshop

BiTS 2015

Handle With Care - Test Cell Integration



Burn-in & Test Strategies Workshop

BiTS 2015

Handle With Care - Test Cell Integration



BiTS 2015

Handle With Care - Test Cell Integration

Device/Carrier Handling

- Standardized InCarrier size for all WLCSP device sizes
 - Same cartridge used for all WLCSP carriers
- InCarrier device handling
 - Device retention exceed "drop test" on hard surface
- Handling WLCSP for Engineering
 - Device handling for characterization
 - Burn-in / Environmental (under investigation)



40 Slot Cartridge



Final Test Solution of WLCSP Devices

Burn-in & Test Strategies Workshop

Handle With Care - Test Cell Integration

InCarrier[®] Layout - Stress on Device

- Carrier springs slide devices to know position in corner for accurate positioning
 - Spring clamping at controlled speed (variable) and all sites in parallel
 - The force is optimized for minimal force againt the device while maintaining position in InCarrier
 - No corners are touched
- Scratches/prints due to springs/carrier sides
 - Zero customer issues reported for damage to devices to date (most in a 6 sigma automotive application)
 - · No scratching issues have arisen





Final Test Solution of WLCSP Devices

Burn-in & Test Strategies Workshop

BiTS 2015

Handle With Care - Test Cell Integration

Die Stress Analysis



Burn-in & Test Strategies Workshop

Handle With Care - Test Cell Integration

Stress Test with WLCSP Devices

Typical test flow would require 1 insertion/retraction of device into carrier (Rework could add a second or third insertion in extreme examples)





Final Test Solution of WLCSP Devices

Burn-in & Test Strategies Workshop

www.bitsworkshop.org

BiTS 2015

Handle With Care - Test Cell Integration



Burn-in & Test Strategies Workshop

BiTS 2015

Handle With Care - Test Cell Integration

Device Loading into carrier



Pick and place from wafer ring



Throughput • Up to 12,000 UPH Placement accuracy • +/- 37um • 1deg theta Missed die handling • Vacuum detection • Vision camera optional • Rules creation for action

Semi E84 (device mapping)

Die Insertion into carrier



Device placement

 1mm or more tolerance for device placement

Carrier device retention

- SW controlled (variable) speed spring operation
- Parallel closing across carrier
- Reliable device retention
 - Tested retention to exceed drop test

InCarrier ready for test



InCarrier identification

Datamatrix visual
identification

Visual inspection of loaded
carrier

Missing/lifted die detection

- •Rules creation for action
- HVM production proven solution

Die pick from wafer ring using same technology as current process



Final Test Solution of WLCSP Devices

12

Burn-in & Test Strategies Workshop

BiTS 2015

Handle With Care - Test Cell Integration



Burn-in & Test Strategies Workshop

Handle With Care - Test Cell Integration

Probe Pattern effects on test



InCarrier offers simplified loadboard layout AND 100% wafer map efficiency



Final Test Solution of WLCSP Devices

Source: Cascade Microtech

Burn-in & Test Strategies Workshop

www.bitsworkshop.org

Handle With Care - Test Cell Integration



8 die 100mm

InCarrier advantages for WLCSP

- •Enables test after wafer sawing
- •100% touch efficiency
- Spacing between DUT's for easier loadboard/probe design
 Improve TTM
- Re-test of single part possible without touching other parts
 Re-test of lots if required (re-test after singulation)



Final Test Solution of WLCSP Devices

Handle With Care - Test Cell Integration

Summary

- Eliminates test escapes created by singulation process
 - Enables true Final Test of WLCSP devices
- Gentle and reliable handling of singulated WLCSP packages
 - Uses same pick and place technique as today's process
 - Carrier placement accuracy supports fine pitch device applications
- Wafer data preserved using industry standards for device tracking
- Increased throughput of test cell



V Test Strategies Wo