BiTS 2017

Teaming Up - Handler / Test Cell



Burn-in & Test Strategies Workshop

www.bitsworkshop.org

March 5-8, 2017

Copyright Notice

The presentation(s)/poster(s) in this publication comprise the Proceedings of the 2017 BiTS Workshop. The content reflects the opinion of the authors and their respective companies. They are reproduced here as they were presented at the 2017 BiTS Workshop. This version of the presentation or poster may differ from the version that was distributed in hardcopy & softcopy form at the 2017 BiTS Workshop. The inclusion of the presentations/posters in this publication does not constitute an endorsement by BiTS Workshop or the workshop's sponsors.

There is NO copyright protection claimed on the presentation/poster content by BiTS Workshop. However, each presentation/poster is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author(s) or their companies.

The BiTS logo and 'Burn-in & Test Strategies Workshop' are trademarks of BiTS Workshop. All rights reserved.



Teaming Up - Handler / Test Cell

BiTS 2017

BiTS Workshop 2017 Schedule Session 7 **Solutions Day** Morten Jensen Session Chair Wednesday March 8 - 8:00 am **Teaming Up** "Applying FEA Simulation for Test Interface Unit" Jason Koh - Test Tooling Solutions Group "BI RHINO Handling Solution" Yaniv Raz- Intel Corporation "Optical Device Testing at Wafer Level and Package Devices" Carl Kasinski – Aehr "Fan-in WLCSP Test Requirements" Mike Frazier - Mike Frazier

Burn-in & Test Strategies Workshop

www.bitsworkshop.org

March 5-8, 2017



BiTS 2017

BI RHINO Handling Solution

Yaniv Raz Intel Corporation



BiTS Workshop March 5 - 8, 2017



Burn-in & Test Strategies Workshop

www.bitsworkshop.org

March 5-8, 2017

Teaming Up - Handler / Test Cell

Background

- MVE (Manufacturing Validation Engineering) is a group at Intel which is responsible for test development and validation of Intel microprocessors.
- MVS (Manufacturing Validation Solution) is a Team within MVE.
- The Team's scope involves delivering complete systems for the validation world, including automation systems.
- The RHINO handler was developed for the BI (Burn-in) validation (Burn-in) validation labs in Intel.

Teaming Up - Handler / Test Cell

BiTS 2017

Problem statement

- Burn In (BI) ovens are being widely used in Intel validation sites, for stress tests purposes.
- BIBs (Burn In Boards) are testing boards which are being loaded to the BI oven.





BI RHINO Handling Solution

Burn-in & Test Strategies Workshop

Teaming Up - Handler / Test Cell

Problem statement

- BIBs are becoming heavier than before, with the latest product BIBs reaching 15 kg.
- The BI ovens includes 16 slots for BIB, while the upper ones requires a ladder to reach for loading.
- As manual loading and unloading the BIBs to the BI oven involves ergonomic hazards, a decision was taken to develop an ergonomic solution to eliminate the risk of operation.



BI RHINO Handling Solution

7

Burn-in & Test Strategies Workshop

Teaming Up - Handler / Test Cell

Solution concept

- Main requirements for the RHINO design team:
 - Eliminate all the ergonomic hazards involved with Loading and unloading of the BI oven.
 - Design a lean footprint and easy to use handler
 - Be able to reach all 16 BI oven slots.
 - Be capable to work with any product related BIB.
 - The Handler can work on a single BIB mode, or on an automated mode (feeding from an 8 BIB cart).
 - System will includes a user friendly UI



Session 7 Presentation 2

Teaming Up - Handler / Test Cell

RHINO Handler Concept

• The RHINO Handler is docked to each BI oven side and serves 16 slots.



Burn-in & Test Strategies Workshop

www.bitsworkshop.org

9

Teaming Up - Handler / Test Cell

BiTS 2017



Burn-in & Test Strategies Workshop

BiTS 2017

Teaming Up - Handler / Test Cell

Mechanical Overview

 The Rhino design can be break down into 2 main mechanisms:

• Lifter

- Handles the up-down movements.
- Carries the loader tray and reaches all 16 BI Oven slots
- Loader tray
 - · Hosts the BIB secured while lifted or lowered
 - Handles the loading and unloading in and out of the BI oven slots



Teaming Up - Handler / Test Cell

BiTS 2017

Lifter

- Lifter mechanism is based on 2 coupled Festo electrical slides.
- Calibration slots location mapping is done with laser sensors.





BI RHINO Handling Solution

Burn-in & Test Strategies Workshop

BiTS 2017

Teaming Up - Handler / Test Cell

Loader Tray

 Conveying mechanism is based on a rotating arm and a popup puller pin which are in charge of pushing and pulling the BIB in and out of the BI oven slots.



• Latching mechanism keeps the BIB secured in place while the lifter is transitioning.



Rotating Arm BIB slides



BI RHINO Handling Solution

Burn-in & Test Strategies Workshop

Teaming Up - Handler / Test Cell

BiTS 2017

Safety Features

- All handler openings are covered by safety curtains, and are finger proof rated.
- Front side lower portion is covered with an optic curtain set (Level 4), while upper is covered by a transparent screen.
- "Person inside" detection is covered by floor horizontal optic curtain.
- While cart is docked, lower curtain is disabled to allow BIB transfers from the cart to the oven and vice versa.





Teaming Up - Handler / Test Cell

RHINO operational overview

Operator is able to choose between 2 modes of operation:

Manual bib loading (single BIB)



Automated loading from a 8 BIB cart





BI RHINO Handling Solution

Burn-in & Test Strategies Workshop

Teaming Up - Handler / Test Cell

Project Summary

- Project goal was fully achieved eliminating all safety and Ergo risks involved with BI ovens loading and unloading.
 - Secondary goals achieved Lean footprint, capability to work in Manual and Auto mode, higher capacity and speed, capable for any product.
- Budget target was met as well machine cost for batches of 4+ is \$60K.
- Customers satisfactory is high.
- Project team:
 - PM \ SE Yaniv Raz
 - Lead Mechanical designer Adi Klein
 - Mechanical designer (student) Andrey Evgraphov
 - Electrical \ SW design Shaniv (External vendor)
- Duration from initiation to 1st article testing ~18 months.



Teaming Up - Handler / Test Cell



Burn-in & Test Strategies Workshop