

Development and Verification of Wet Testing Platform for BioMEMS Chips

Po-Ting Lai
King Yuan ELECTRONICS CO.



Shanghai - October 31, 2024



Outline

- Introduction
- Establish testing platform
- Experience Result
- Conclusion and discussion



Development and Verification of Wet Testing Platform for BioMEMS Chips



2

Outline

- Introduction
- Establish testing platform
- Experience Result
- Conclusion and discussion




Development and Verification of Wet Testing Platform for BioMEMS Chips



3


BioMEMS introduction

- ◆ BioMEMS is a rapidly developing field and BioMEMS can be applied to a wide area.
- ◆ After the outbreak of COVID-19, many medical companies have invested in the development of new types of BioMEMS.




BioMEMS introduction

- ◆ MEMS technology can reduce the size of Biomedical chips. The testing requires only a small amount of sample, reagent, and testing.
- ◆ Various companies are actively engaged in the fields of cancer detection, drug testing, home care (point of care) and rapid DNA sequencing.



BioMEMS in DNA sequence

- ◆ DNA sequencing is a key application of BioMEMS, where MEMS devices with biological sensing layers allow for rapid gene detection.
- ◆ BioMEMS-based DNA sequencing provides fast, accurate, and cost-effective gene analysis, that can be widely used in cancer risk assessment, prenatal screening, and pathogen detection.



Development and Verification of Wet Testing Platform for BioMEMS Chips

Testing for BioMEMS

- ◆ Most biomedical chips operate in an aqueous environment, while conventional semiconductor testing measures electrical signals in dry conditions.
- ◆ The lack of advanced mass production testing technologies limits BioMEMS production capacity due to low testing coverage.
- ◆ Testing in liquid environments introduces challenges such as evaporation, incomplete coverage, and cleaning residue, which can affect measurement accuracy.



Outline

- Introduction
- **Establish testing platform**
- Experience Result
- Conclusion and discussion




Development and Verification of Wet Testing Platform for BioMEMS Chips




8

Wet testing process protocol

- ◆ 2 pads and 1 sensing area in each test key and 5 test key on each die.
- ◆ During wet testing, it is necessary to dispense the test solution onto the sensing area and probe on the pad.
- ◆ When 1 μl droplet was dispensed at the center of the array, the distance between the droplet and the pad **is** only 1.25mm.



Droplet diameter simulated





Wet testing process protocol

- ◆ The test platform **is** integrated with probe station, semiconductor electrical analyzer, and microfluidic control system.
- ◆ 2 micropositioners with Kelvin pins and 2 micropositioners with dispensing tip were added on TS150 for wet ting.




Capacitance testing system setting

- ◆ The semiconductor analyzer B1500A selected the capacitance-to-time (C-t) mode for measurement.




Parameter	
B1500A C-t Measure	
Voltage range	1 V
Interval	500ms
Frequency	1k Hz
Total sample data	7201
Test time	1 hr
Pump	
Flow rate (ul/min)	0.5
Test solution volume (ul)	1
Clean solution volume (ul)	1


Wet testing process establish



Chip and position



Dispense solution and wet testing



Outline

- Introduction
- Establish testing platform
- Experience Result
- Conclusion and discussion




Development and Verification of Wet Testing Platform for BioMEMS Chips




13

Short-term C-t result and characteristic verification

- ◆ Capacitance value increased continuously within one measurement.
- ◆ The **initial** and average capacitance values were higher and higher when more experiments was conducted.
 - The reaction time is an important factor in this chip.



Chip A #003 Test Key 0.5M NaCl C-t Test Summary					
Test Key	1	2	3	4	5
Average (pF)	53.59	40.09	39.89	51.56	52.29
S.D. (pF)	3.24	2.56	2.61	3.06	1.67



C-t test	
Vbase (V)	± 1
OscLevel (mV)	50
Frequency (Hz)	1K
Total sample data	121
Test time (Sec)	60



Development and Verification of Wet Testing Platform for BioMEMS Chips



Preliminary long-term characteristic verification



- ◆ Conducted long-term examination to further analyze chip characteristic.
- ◆ As the testing solution used should be less than 1 μl , it evaporates easily.
 - Keep **replenishing the** test solution when evaporation **happens**:
 1. Replenish DI H_2O , concentration of test solution will keep **it** in 1M.
 2. Replenish 1M NaCl, concentration of test solution will increase.

Examination process





Water-retaining shield method

- ◆ Water-retaining shield method **can prevent** the test solution **from contacting** the pad.
- ◆ Shield can **isolate** the test solution from **the** environment and increase the volume of the testing solution.




Water-retaining shield method

- ◆ Shield method **can** effectively reduce the solution evaporation rate.
- ◆ 1ul NaCl still **remains at** 10% volume after 2hr in shield method.




PTFE shield



PDMS shield


Water-retaining shield method

- ◆ In shield group, capacitance value increased from 20 pF to 30 pF.
- ◆ In control group, capacitance value increased from 20 pF to 55 pF.
 - Shield method could prevent the testing solution evaporation and **made the** signal more stable in 1 hr C-t test.



Long-term repeatability verification



- ◆ Using shield method to verify the test platform repeatability and analyze chip characteristic.
 - Three times of the capacitance measurement values remained consistent.



Chip A#004 Test Key2 1M NaCl C-t Test			
Test number	1	2	3
INIT (pF)	9.81	10.1	12.3
AVG (pF)	11.25	10.29	14.80
STD (pF)	1.31	2.12	2.78

Short-term repeatability verification

- ◆ According previous experience, optimized the test platform and developed final process.



Short-term repeatability verification

- ◆ There are 4 **groups based** on capacitance value, Super High (> 1000 pF), High (1000 pF ~ 500 pF), Medium (500 pF ~ 100 pF), and Low (<100 pF).
 - **Results** from 30 test keys **showed both** high **stability** and accuracy.



Outline

- Introduction
- Establish testing platform
- Experience Result
- **Conclusion and discussion**



Development and Verification of Wet Testing Platform for BioMEMS Chips



22

Conclusion and discussion

- ◆ To meet the wet testing requirements of BioMEMS chips, we developed an integrated platform that ensures reliable measurement accuracy.
- ◆ Testing platform developed based on probe station, has the potential for full automation and is currently under development.
- ◆ **Supports** our client in enhancing their manufacturing process by analyzing the characteristics of this BioMEMS chip.

COPYRIGHT NOTICE

The presentations in this publication comprise the pre-workshop Proceedings of the TestConX China workshop. They reflect the authors' opinions and are reproduced here as they are planned to be presented at TestConX China. Updates from this version of the papers may occur in the version that is actually presented at TestConX China. The inclusion of the papers in this publication does not constitute an endorsement by TestConX or the sponsors.

There is NO copyright protection claimed by this publication. However, each presentation is the work of the authors and their respective companies: as such, it is strongly encouraged that any use reflect proper acknowledgement to the appropriate source. Any questions regarding the use of any materials presented should be directed to the author/s or their companies.

The TestConX logo, 'TestConX', and 'TestConX China' are trademarks of TestConX.